

FXN 1121|FLEXIBLE NEON PIVOT MOUNTING BRACKET

Friendly Reminder – Please read instructions carefully before operation

Step 1

Step 2

Step 3

Step 1:
Remove the upper screw from pivot mounting bracket.

Step 2:
Fix pivot mounting bracket and mounting profile tightly by the screw.

Step 3:
Repeat step 1 & step 2 for the remaining brackets and secure at least 2 locking points for each mounting profile, and the equal interval is more recommended.

Warning:

Keep pivot mounting bracket and mounting profile parallel from the side view.

Step 4

Rotate pivot mounting bracket till the showing up of the unfixed screw hole to facilitate the installation with mounting surface as per the pre-marked hole.

Step 5

Fix pivot mounting bracket to mounting surface by KA3.5*25 screw.

Step 6

Adjust the angle of mounting profile to the one required.

Step 7

Tighten the side screws of pivot mounting bracket to avoid loosened locking point.